



**Le
Presse
Papier**
LYON

NOTICE D'INSTALLATION

Suivant DTU 59.4

Mise en oeuvre des papiers peints et des revêtements muraux

MATÉRIEL :

- Fil à plomb ou règle à niveau
 - Crayon à papier
- Colle pour papier peint intissé
 - Brosse à maroufler
 - Roulette de tapissier
 - Cutter
 - Règle

AVANT DE COMMENCER :

Veillez toujours à ce que le mur soit lisse, propre et sec.
Si celui-ci présente des aspérités, poncez-le avec le grain
de papier de verre approprié.

Enlevez les caches des interrupteurs et des prises. Vous les
replacerez après installation.

Afin de poser votre premier lé le plus droit possible, munis-
sez-vous d'une règle à niveau ou d'un fil à plomb. Tracez une
ligne droite à 62cm du bord du mur, vous suivrez ce repère avec
votre premier lé.

Une couleur sous couche sous les joints peut être appliquée.

COLLE :

Nos papiers-peints sont des intissés, il existe de la colle spécifique pour cette matière, que l'on vous encourage à utiliser « sans solvants ».

Préparez la colle comme indiqué sur le mode d'emploi du produit.

Etalez directement la colle sur le mur à l'aide d'un rouleau ou d'une brosse à encoller.

LA POSE :

Déroulez votre rouleau et partez du haut du mur.

Si le mur n'est pas droit, partez du côté le plus haut ou bien faites dépasser votre papier-peint de quelques 2-3cm.

Maroufflez le papier avec une brosse spéciale en partant de l'intérieur vers l'extérieur pour chasser l'air.

Découpez le surplus au niveau des plinthes et du plafond en vous aidant d'un cutter et d'une règle.

Passez la roulette de tapissier sur le bord des lés pour éviter qu'ils ne se relèvent.

INSTALLATION NOTICE

Following DTU 59.4
Application instructions for wallpaper and wall coverings

EQUIPMENT :

- Plumb line or level
 - Pencil
- Paste for non-woven wallpaper
 - Smoothing brush
- Wallpaper Seam Roller
 - Cutter
- Ruler or straightedge

BEFORE YOU BEGIN :

Ensure that the wall is clean, smooth and dry. If there are irregularities, smooth using the proper type of sandpaper.

Remove light switch covers and sockets.
You will re-install them when you've finished.

To ensure that the first panel is as straight as possible, use a ruler and a level or plumb line.
Measure 62cm from the edge of the wall and draw a straight vertical line as a reference when applying the first panel of wallpaper.

PASTE :

Our wallpapers are non-woven.
There is a special kind of adhesive for this material; we recommend using «solvent-free» wallpaper paste.

Prepare the paste as indicated in the product recommendations.

Apply the paste directly to the wall using a roller or a glue brush.

HANGING :

Unroll your wallpaper and start from the top of the wall.

If the wall isn't straight, start from the highest point; alternatively leave an extra 2-3cm of wallpaper at the top.

Smooth paper with a special brush,
moving outward from the center to remove air bubbles.

Using a ruler and a cutter, trim surplus at ceiling and
baseboard.

With the seam roller, flatten the edges to prevent detaching.

Fabriqué en France / Made in France

Composition :
Papier intissé / Non-woven paper

Adresse :
Le Presse Papier
5 place Louis Chazette
69001 Lyon

www.le-presse-papier.fr

CE



Imprim
Luxe®

